Kutchan House
HOW TO USE POOL SYSTEM TO MELT THE SNOW





The red circle is power supply. The yellow circle is button ON/OFF.



Be careful with power supply. Don't plug off the power supply



Button ON/OFF for water supply.



The snow melting pool.



There is a heater in the white box where the water come from.

HOW TO USE SNOW MELTING POOL



1. Throw the snow into the pool



2. Turn ON the water supply system

WARNING :

Kutchan House

HOW TO USE POOL SYSTEM TO MELT THE SNOW

- Be aware that you are sharing the water table underground with your neighbors, so please don't leave the water supply system ON for more than 3-4 hours straight.

- Switch off after use, don't keep it ON for the whole night.

- Don't put too much snow in the pool, you can use the other designated area to put the snow (see snowclearing roof manual).

- Be careful with power supply near the box. Don't plug off the power supply.

- Don't remove the pool's drain pipe, there is a risk of blocking the drain.

- If the water doesn't come out, turn off the system for a few hours until it goes back to normal.

- If it is still not working, you have to prime the pump putting water in the pipe before turning it ON again.



Pool's drain pipe



Prime the pump with a bucket.

END OF MARCH/END OF SEASON :

Kutchan House

HOW TO USE POOL SYSTEM TO MELT THE SNOW

1. Take the remaining water from the pool with a bucket



2. Remove the gravel from the pool with a shovel and change the drain pipe to the flat filter.



3. Turn OFF the main electricity breaker in the house.