Kutchan House

HOW TO REMOVE SNOW FROM THE ROOF







1. Start from the edge of your roof when you are attempting to remove snow yourself and work your way onto the roof from there.
2. Use plastic roof snow removal tools, such as a snow rake for pitched roofs.



3. Try to keep a buildup of snow away from fire escapes, emergency building exits, drain downspouts, and ventilation openings .
4. Don't use metal equipment in attempts to remove snow from your rooftop. This will not efficiently remove the snow and may very well do more harm than good.



5. Use sleds to transport the snow easily.









6. Use the ladder to remove snow on rooftop.



7. Be careful with your step when standing on rooftop.







8. Use mumasan dump (green thing) to clear snow on rooftop and watch your step.







9.Use the sleds to easy transport the snow.







10. Be careful in the back of the house. Make sure the snow is not thrown on the oil tank and the windows.








11. Throw the snow at pool system to melt the snow.

11. There is another area where you can dumb the snow. Make sure you dump it at the back of the snow pile.





AFTER FINISH.



FRONT.



SIDE.



BACK.